

410E Backhoe Loader Repair

TECHNICAL MANUAL

TM1611 22JUL10 (ENGLISH)

For complete service information also see:

| | |
|---|---------|
| 410E Backhoe Loader Repair (Complete) | TM1611 |
| 410E Backhoe Loader Operation and Test (Complete)..... | TM1610 |
| POWERTECH® 4.5 L (4045) Engine | CTM104 |
| Alternators and Starting Motors | CTM77 |
| Front Wheel Drive Axles APL-2025..... | CTM4509 |


**Worldwide Construction
And Forestry Division**
LITHO IN U.S.A.

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

See DB1990 Service Publications Catalog to order a complete Technical Manual (TM) or a Technical Manual Section (TMS). A complete Repair manual includes the following sections:

- TMS161100 Section 00 General Information
- TMS161101 Sections 01—02 Wheels and Axles
- TMS161103 Sections 03—06 Transmission and Engine
- TMS161109 Sections 09—11 Steering and Brakes
- TMS161116 Sections 16—17 Electrical System and Frame
- TMS161118 Sections 18—20 Operator's Station and Sheet Metal
- TMS161121 Sections 21, 31, 33 Main Hydraulics

TX,INTR,SS3531 -19-11DEC96-1/1

John Deere Dealers

IMPORTANT: Please remove this page and route through your service department.

Listed below is a brief explanation of “WHAT” was change and “WHY” it was changed.

These sectionalized manuals were revised to include the following changes:

1. Section 00:
To include any specifications, oil capacity and miscellaneous changes.
2. Section 01—02:
Miscellaneous wheel specification changes and service brake check added.
3. Section 03—06:
Transmission clutch pack bottom of gear to top of drum distance specification change, miscellaneous changes in charge pump and manifold plate solenoids procedures.
4. Engine flywheel turning tool number change. Fan cap screw torque added.
5. Section 09—11:
Steering valve manual check valve change. Miscellaneous brake valve changes.
6. Section 16—17:
Torque added to engine coolant temperature switch.
7. Section 18—20:
Cab side window torque and thread lock and sealer added. Bushings added to guide on upper rear window. Air suspension seat procedure added.
8. Section 21, 31 and 33:
Torque added to hydraulic pump unloader relief valve. Cooler options added. Multi-purpose bucket and lines added. Shim as required added to bucket links-to-cylinder. Loader control relief valves torques, graphics and procedure changes. Loader cylinder miscellaneous changes. Backhoe linkage changes. Backhoe boom swing lock arms and locking pin added. Stabilizer valve linkage updates and serial number breaks. Miscellaneous changes to extensible dipperstick and sideshift frame locking pistons. Backhoe control relief valves torques, graphics and procedure changes. Backhoe cylinders serial number breaks and procedure changes. Extendible dipperstick disassemble and assemble procedure added.

CED, TX03399, 5903 -19-13JAN00-1/1

Technical Information Feedback Form

We need your help to continually improve our technical publications. Please copy this page and FAX or mail your comments, ideas and improvements.

SEND TO: John Deere Dubuque Works
18600 South John Deere Road
Attn: Publications, Dept. 324
Dubuque, IA 52004-0538
USA

FAX NUMBER: 1-563-589-5800 (USA)

Publication Number: _____

Page Number: _____

Ideas, Comments: _____

Name: _____

Phone: _____

Email Address: _____

THANK YOU!

TX,TM,FAX -19-03JUL01-1/1

Contents

Section 00—General Information

- Group 0001—Safety Information
- Group 0002—General Specifications
- Group 0003—Torque Values
- Group 0004—Fuels and Lubricants

Section 01—Wheels

- Group 0110—Powered or Non-Powered Wheels and Fastenings

Section 02—Axles and Suspension Systems

- Group 0225—Input Drive Shafts and U-Joints
- Group 0230—Non-Powered Wheel Axles
- Group 0240—Powered Wheel Axle (MFWD)
- Group 0250—Axle Shaft, Bearings and Reduction Gears
- Group 0299—Dealer Fabricated Tools

Section 03—Transmission

- Group 0300—Removal and Installation
- Group 0315—Controls Linkage
- Group 0325—Input Drive Shafts and U-Joint
- Group 0350—Gears, Shafts, Bearings, and Powershift Clutches
- Group 0360—Hydraulic System
- Group 0399—Dealer Fabricated Tools

Section 04—Engine

- Group 0400—Removal and Installation
- Group 0499—Dealer Fabricated Tools

Section 05—Engine Auxiliary Systems

- Group 0505—Cold Weather Starting Aid
- Group 0510—Cooling Systems
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0530—Exhaust System
- Group 0560—External Fuel Supply System

Section 06—Torque Converter

- Group 0651—Turbine, Gears and Shaft

Section 09—Steering System

- Group 0960—Hydraulic System

Section 10—Service Brakes

- Group 1011—Active Elements

- Group 1060—Hydraulic System

Section 11—Park Brake

- Group 1111—Active Elements

Section 16—Electrical Systems

- Group 1671—Batteries, Support, and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness and Switches
- Group 1675—System Controls
- Group 1676—Instruments and Indicators
- Group 1677—Motors and Actuators

Section 17—Frames, Chassis or Supporting Structure

- Group 1740—Frame Installation
- Group 1749—Chassis Weights

Section 18—Operator's Station

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning
- Group 1899—Dealer Fabricated Tools

Section 19—Sheet Metal and Styling

- Group 1910—Hood and Engine Enclosure
- Group 1913—Miscellaneous Shields
- Group 1921—Grille and Grille Housing
- Group 1927—Fenders

Section 20—Safety, Convenience and Miscellaneous

- Group 2001—Radio
- Group 2004—Horn and Warning Devices

Section 21—Main Hydraulic System

- Group 2160—Hydraulic System

Section 31—Loader

- Group 3100—Loader
- Group 3102—Bucket
- Group 3115—Control Linkages
- Group 3160—Hydraulic System

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2002
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION © Manual
Previous Editions
Copyright © 1997, 1999, 2000

Section 33—Backhoe

Group 3302—Bucket

Group 3315—Control Linkage

Group 3340—Frames

Group 3360—Hydraulic System

Section 00 General Information

Contents

| | Page | | Page |
|--|------------|--|-----------|
| Group 0001—Safety Information | | | |
| Handle Fluids Safely—Avoid | | Metric Bolt and Screw Torque | |
| Fires..... | 00-0001-1 | Values..... | 00-0003-2 |
| Prevent Battery Explosions..... | 00-0001-1 | Additional Metric Cap Screw | |
| Prepare for Emergencies..... | 00-0001-1 | Torque Values..... | 00-0003-3 |
| Prevent Acid Burns..... | 00-0001-2 | Unified Inch Bolt and Screw Torque | |
| Handle Chemical Products Safely..... | 00-0001-2 | Values..... | 00-0003-4 |
| Avoid High-Pressure Fluids..... | 00-0001-3 | O-Ring Groove Connections..... | 00-0003-5 |
| Park Machine Safely..... | 00-0001-3 | Check Oil Lines And Fittings..... | 00-0003-5 |
| Support Machine Properly..... | 00-0001-3 | Service Recommendations for | |
| Wear Protective Clothing..... | 00-0001-4 | O-Ring Boss Fittings..... | 00-0003-6 |
| Work in Clean Area..... | 00-0001-4 | Service Recommendations for Flat | |
| Service Machines Safely..... | 00-0001-4 | Face O-Ring Seal Fittings..... | 00-0003-7 |
| Work In Ventilated Area..... | 00-0001-5 | Service Recommendations for | |
| Illuminate Work Area Safely..... | 00-0001-5 | Metric Series Four Bolt Flange | |
| Replace Safety Signs..... | 00-0001-5 | Fitting..... | 00-0003-8 |
| Use Proper Lifting Equipment..... | 00-0001-6 | Service Recommendations For | |
| Remove Paint Before Welding or | | Inch Series Four Bolt Flange | |
| Heating..... | 00-0001-6 | Fittings..... | 00-0003-9 |
| Avoid Heating Near Pressurized | | Group 0004—Fuels and Lubricants | |
| Fluid Lines..... | 00-0001-6 | Diesel Fuel..... | 00-0004-1 |
| Keep ROPS Installed Properly..... | 00-0001-7 | Low Sulfur Diesel Fuel | |
| Service Tires Safely..... | 00-0001-7 | Conditioner..... | 00-0004-1 |
| Practice Safe Maintenance..... | 00-0001-8 | Handling and Storing Diesel Fuel..... | 00-0004-2 |
| Use Proper Tools..... | 00-0001-8 | Do Not Use Galvanized | |
| Dispose of Waste Properly..... | 00-0001-9 | Containers..... | 00-0004-2 |
| Live With Safety..... | 00-0001-9 | Heavy Duty Diesel Engine | |
| Group 0002—General Specifications | | Coolant..... | 00-0004-3 |
| 410E Backhoe Loader | | Fuel Tank..... | 00-0004-3 |
| Dimensions..... | 00-0002-1 | Diesel Engine Oil..... | 00-0004-4 |
| 410E Backhoe Loader | | Transmission, Axle, and | |
| Specifications..... | 00-0002-6 | Mechanical Front Wheel Drive | |
| Other Information—410E Backhoe | | Oil..... | 00-0004-5 |
| Loader..... | 00-0002-8 | Hydraulic Oil..... | 00-0004-5 |
| 410E Backhoe Loader Weight..... | 00-0002-8 | Grease..... | 00-0004-7 |
| 410E Backhoe and Loader | | Grease for Extendible Dipperstick, | |
| Buckets..... | 00-0002-9 | Sideshift Frame, and Stabilizer | |
| 410E Backhoe Loader Drain and | | Leg Wear Strips..... | 00-0004-7 |
| Refill Capacities..... | 00-0002-9 | Alternative and Synthetic | |
| 410E Backhoe Loader Lifting | | Lubricants..... | 00-0004-7 |
| Capacities—Standard | | Lubricant Storage..... | 00-0004-8 |
| Dipperstick..... | 00-0002-10 | Mixing of Lubricants..... | 00-0004-8 |
| 410E Backhoe Loader Lifting | | | |
| Capacities—Extendible | | | |
| Dipperstick (Retracted)..... | 00-0002-11 | | |
| 410E Backhoe Loader Lifting | | | |
| Capacities—Extendible | | | |
| Dipperstick (Extended)..... | 00-0002-12 | | |
| Group 0003—Torque Values | | | |
| Hardware Torque Specifications..... | 00-0003-1 | | |
| ROPS Torque Specifications..... | 00-0003-1 | | |

Contents

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



TS227—UN—23AUG88

DX,FLAME -19-29SEP98-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204—UN—23AUG88


DX,SPARKS -19-03MAR93-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291—UN—23AUG88

DX,FIRE2 -19-03MAR93-1/1

Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203—UN—23AUG88

DX,POISON -19-21APR93-1/1

Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132—UN—26NOV90

DX,MSDS,NA -19-03MAR93-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in



X9811 —UN—23AUG88


Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.

DX,FLUID -19-20AUG09-1/1

Park Machine Safely

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



TS230 —UN—24MAY89


DX,PARK -19-04JUN90-1/1

Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If the work requires that the machine or attachment be lifted, provide secure support for them. If left in a raised position, hydraulically supported devices can settle or leak down.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

When implements or attachments are used with a machine, always follow safety precautions listed in the implement or attachment operator's manual.



TS229 —UN—23AUG88


DX,LOWER -19-24FEB00-1/1

Safety Information

Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




TS206—UN—23AUG88

DX,WEAR2 -19-03MAR93-1/1

Work in Clean Area

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




T6642EJ—UN—18OCT88

DX,CLEAN -19-04JUN90-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228—UN—23AUG88

DX,LOOSE -19-04JUN90-1/1

Safety Information

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




TS220 —UN—23AUG88

DX,AIR -19-17FEB99-1/1

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




TS223 —UN—23AUG88

DX,LIGHT -19-04JUN90-1/1

Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




TS201 —UN—23AUG88

DX,SIGNS1 -19-04JUN90-1/1

Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



TS226—UN—23AUG88

DX,LIFT -19-04JUN90-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.



TS220—UN—23AUG88

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

DX,PAINT -19-24JUL02-1/1

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can accidentally burst when heat goes beyond the immediate flame area.




TS953—UN—15MAY90

DX,TORCH -19-10DEC04-1/1

Keep ROPS Installed Properly

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



TS212—UN—23AUG88

DX,ROPS3 -19-03MAR93-1/1

Service Tires Safely


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



TS211—UN—23AUG88

DX,RIM -19-24AUG90-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



TS218 —UN—23AUG88

DX,SERV -19-17FEB99-1/1

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 —UN—08NOV89

DX,REPAIR -19-17FEB99-1/1

Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 —UN—26NOV90

DX,DRAIN -19-03MAR93-1/1

Live With Safety

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.




TS231 —19—07OCT88

DX,LIVE -19-25SEP92-1/1

Safety Information

410E Backhoe Loader Dimensions



T115805

T115805—UN—11JUN98

NOTE: Specifications and design subject to change without notice. Whenever applicable, specifications are in accordance with SAE Standards unless otherwise noted, these specifications are based on a standard machine with 19.5L-24, 8PR, R4

rear tires; 11L-16, 12PR, F3 front tires; 0.86 m³ (1.12 cu yd) loader bucket; 610 mm (24 in.) backhoe bucket; ROPS/FOPS; full fuel tank and 79 kg (175 lb) operator.

| Item | Measurement | Specification |
|--|-------------|----------------------|
| A—Loading Height, Truck Loading Position | | |
| Backhoe w/o Ext. Dipperstick | Height | 3.81 m (12 ft 6 in.) |

Continued on next page

TX,110,BD2412 -19-10JUN98-1/5

General Specifications

| Item | Measurement | Specification |
|---|--------------------|-----------------------|
| Backhoe w/Ext. Dipperstick Retracted | Height | 3.86 m (12 ft 8 in.) |
| Backhoe w/Ext. Dipperstick Extended | Height | 4.72 m (15 ft 6 in.) |
| B—Reach from Center of Swing Mast | | |
| Backhoe w/o Ext. Dipperstick | Distance | 5.99 m (19 ft 8 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Distance | 6.07 m (19 ft 11 in.) |
| Backhoe w/Ext. Dipperstick Extended | Distance | 7.21 m (23 ft 8 in.) |
| C—Reach From center of Rear Axle | | |
| Backhoe w/o Ext. Dipperstick | Distance | 7.11 m (23 ft 4 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Distance | 7.19 m (23 ft 7 in.) |
| Backhoe w/Ext. Dipperstick Extended | Distance | 8.33 m (27 ft 4 in.) |
| D—Maximum Digging Depth | | |
| Backhoe w/o Ext. Dipperstick | Depth | 4.83 m (15 ft 10 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Depth | 4.90 m (16 ft 1 in.) |
| Backhoe w/Ext. Dipperstick Extended | Depth | 6.10 m (20 ft 0 in.) |
| E—Digging Depth (SAE)—610 mm (2 ft) Flat Bottom | | |
| Backhoe w/o Ext. Dipperstick | Distance | 4.78 m (15 ft 8 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Distance | 4.85 m (15 ft 11 in.) |
| Backhoe w/Ext. Dipperstick Extended | Distance | 6.07 m (19 ft 11 in.) |
| F—Digging Depth (SAE)—2440 mm (8 ft) Flat Bottom | | |
| Backhoe w/o Ext. Dipperstick | Distance | 4.45 m (14 ft 7 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Distance | 4.55 m (14 ft 11 in.) |
| Backhoe w/Ext. Dipperstick Extended | Distance | 5.82 m (19 ft 1 in.) |
| G—Ground Clearance Minimum | | |
| Backhoe w/o Ext. Dipperstick | Clearance | 356 mm (14 in.) |
| Backhoe w/Ext. Dipperstick Retracted | Clearance | 356 mm (14 in.) |
| Backhoe w/Ext. Dipperstick Extended | Clearance | 356 mm (14 in.) |

Continued on next page

TX,110,BD2412 -19-10JUN98-2/5

Click on the image link below for the full version of the service manual

