

9400, 9500, and 9600 Combines Repairs

**John Deere Harvester Works
TM1401 (28JUL97)**

LITHO IN U.S.A.
ENGLISH

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

Contents

SECTION 10—GENERAL

- Group 05—Safety
- Group 10—Identification Number Location
- Group 15—Specifications
- Group 20—Tune Up and Adjustment
- Group 25—Fuels and Lubricants

SECTION 20—ENGINE

- Group 05—Remove and Install Engine
- Group 10—Cooling System
- Group 15—Lower Engine Repair

SECTION 30—FUEL AND AIR REPAIR

- Group 05—Air Intake System
- Group 10—Diesel Fuel System

SECTION 40—ELECTRICAL SYSTEM

- Group 05—Components
- Group 10—Bulbs and Switches
- Group 15—Batteries
- Group 20—Harness and Connector Repair
- Group 25—Gauges and Monitors
- Group 30—Wiper and Radio
- Group 35—Alternator
- Group 40—Starting Motor
- Group 45—Electrical Engine Control

SECTION 50—POWER TRAIN REPAIR

- Group 05—Transmission and Differential
- Group 10—Ring and Pinion Final Drive
- Group 15—Planetary Final Drive
- Group 20—Hydrostatic System
- Group 25—Cam Lobe Motor
- Group 30—Tires and Wheels

SECTION 60—Power Steering and Brakes

- Group 05—Steering
- Group 10—Brakes

SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Reservoir
- Group 10—Hydraulic Pumps
- Group 15—Hydraulic Valves

- Group 20—Hydraulic Cylinders
- Group 25—Motors
- Group 30—Accumulator
- Group 35—Reel/Belt Pickup Pump Drive

SECTION 80—SEPARATOR SHELL

- Group 05—Gull Wing Doors

SECTION 90—OPERATOR STATION REPAIR

- Group 05—Air Conditioning System (R-12)—Type A
- Group 10—Air Conditioning System (R134A)—Type B
- Group 15—System Components
- Group 20—Cab

SECTION 110—FEEDER HOUSE REPAIR

- Group 05—Feeder House/Conveyor
- Group 10—Feeder House Conveyor Drum
- Group 15—Conveyor Shaft and Slip Clutch
- Group 20—Feeder House Drives and Reverser Gear Case
- Group 25—CONTOUR MASTER Platform Driveshafts
- Group 30—CONTOUR MASTER Tilt Cylinder
- Group 35—CONTOUR MASTER Tilt Frame
- Group 40—CONTOUR MASTER Feeder House

SECTION 120—SEPARATOR

- Group 05—Separator Repair
- Group 10—Cylinder Drives
- Group 15—Straw Walkers and Crankshafts
- Group 20—Straw Chopper, Straw Spreader and Chaff Spreader
- Group 25—Shoe Supply Augers, Cleaning Fan and Chaffer and Sieve Frame
- Group 30—Tailings Elevator and Augers
- Group 35—Primary Countershaft Gearcase
- Group 40—Header Electromagnetic Clutch

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1401-19-28JUL97

COPYRIGHT© 1997
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1994, 1992, 1989, 1988 Deere & Company

**SECTION 130—GRAIN TANK AND UNLOADING
SYSTEM REPAIR**

- Group 05—Grain Tank Cross Augers
- Group 10—Unloading Auger System Drives
- Group 15—Vertical Unloading Auger and Lower Gearcase
- Group 20—Horizontal Unloading Auger and Gearcase
- Group 25—Upper Clean Grain Elevator
- Group 30—Grain Tank and Extensions
- Group 35—Clean Grain Elevator and Loading Auger Gear Case

**SECTION 140—ENGINE GEARCASE AND
CONTROL VALVE REPAIR**

- Group 05—Engine Gearcase and Valve

**SECTION 160—DIAL-A-MATIC HEADER HEIGHT
CONTROL**

- Group 05—Dial-A-Matic Header Height Control

Index

Section 10 GENERAL

Contents

	Page		Page
Group 05—Safety	10-05-1	Engine Coolant	10-25-3
Group 10—Identification Number Location		Liquid Coolant Conditioner	10-25-3
Combine Identification Number	10-10-1	Engine Oil	10-25-4
Transmission	10-10-1	Greases	10-25-7
Engine Serial Number for 9400 Combines	10-10-1	Lubricant Storage	10-25-7
Hydrostatic Drive Unit Pump	10-10-2	Alternative and Synthetic Lubricants	10-25-8
Hydrostatic Drive Unit Motor	10-10-2	Filter Part Numbers	10-25-8
Cam Lobe 4-Wheel Drive Motor	10-10-2		
Engine Gearcase	10-10-2		
Cab	10-10-3		
Group 15—Specifications			
Specifications—9400 Combines	10-15-1		
Operating Speeds—9400 Combines	10-15-3		
Ground Speeds (Separator Full Load)	10-15-4		
Specifications—9500 Combines	10-15-5		
Operating Speeds—9500 Combines	10-15-7		
Ground Speeds	10-15-8		
Specifications—9600 Combines	10-15-9		
Operating Speeds—9600 Combines	10-15-11		
Dimensions	10-15-14		
Metric Bolt and Cap Screw Torque			
Values	10-15-15		
Unified Inch Bolt and Cap Screw Torque			
Values	10-15-16		
O-Ring Boss Fitting Torque Chart	10-15-17		
Flat Face O-Ring Seal Fitting Torque			
Chart	10-15-18		
SAE Four Bolt Flange Fitting Torque			
Chart	10-15-19		
Prevent Hydraulic System Contamination	10-15-20		
Check Oil Lines and Fittings	10-15-21		
Group 20—Tune Up and Adjustment			
Tune-Up and Adjustment	10-20-1		
Care and Maintenance of Belts	10-20-2		
Defective Belts	10-20-3		
Right-Hand Drives and Part Numbers	10-20-5		
Left-Hand Drives and Part Numbers	10-20-7		
Group 25—Fuels and Lubricants			
Diesel Fuel	10-25-1		
Fuel Storage	10-25-2		